



- Hronograf**  
(Start / Stop / Reset)
- ① Start: pritisnite dugme A
  - ② Stop: pritisnite dugme A jednom i očitajte vreme  
1h / 20min / 10 sec.
  - ③ restart:  
pritisnite dugme B

